

## New Lift-Out Mounting Board

1. REMOVE FRONT MOLDING ASSEMBLY AND CASH BOX. RAISE PLAYFIELD PANEL TO ITS HIGH POSITION.
2. REMOVE (4) BOLTS & WASHERS AND (2) SCREWS THAT SECURE MOUNTING BOARD TO CABINET.
3. WITH POWER TO GAME OFF, DIS-CONNECT (2) PLUGS AT LEFT FRONT CORNER OF MOUNTING BOARD.
4. SLIDE MOUNTING BOARD FORWARD ABOUT AN INCH, THEN SLOWLY PULL BOARD FORWARD AND UP, WATCHING REAR OF BOARD FOR CLEARANCE OF PLAYFIELD PANEL. INSERT SUPPORT BLOCK ATTACHED TO UNDERSIDE OF MOUNTING BOARD INTO RECESSED AREA OF FRONT MOLDING LOCK PLATE TO SECURE BOARD.
5. RE-CONNECT ONLY THE FRONT DOOR PLUG AND TURN POWER TO GAME ON. GAME CAN NOW BE OPERATED FOR SERVICING, WITH EASY ACCESS TO ALL GAME COMPONENTS ON RAISED MOUNTING BOARD.
6. WHEN RETURNING MOUNTING BOARD TO CABINET, ALWAYS TURN POWER TO GAME OFF FIRST, THEN DIS-CONNECT THE FRONT DOOR PLUG AND SLOWLY LOWER BOARD BACK INTO CABINET. RE-CONNECT THE (2) MOUNTING BOARD PLUGS, TURN POWER ON, AND GAME IS AGAIN READY FOR REGULAR OPERATION.

### NOTE;

WHEN GAME IS INSTALLED ON LOCATION, THE (4) MOUNTING BOARD BOLTS & WASHERS CAN BE REMOVED PERMANENTLY. THE (2) SCREWS ARE SUFFICIENT TO PREVENT ANY MOVEMENT OF BOARD WHILE GAME IS IN OPERATION.

