

BANK SHOT MOTOR SWITCHES

MOTOR 1A (S-POS)	Inside Sw. Second Sw. Third Sw.	<ul style="list-style-type: none">- Adds ball count and bonus unit.- Subtracts ball count unit.- Scoring.
MOTOR 1B	Inside Sw. Second Sw.	<ul style="list-style-type: none">- Hole score control switch.- Actuates "H" relay on tilt.
MOTOR 1C (S-POS)	Inside Sw. Second Sw. Third Sw. Fourth Sw. Fifth Sw. Sixth Sw.	<ul style="list-style-type: none">- Motor runout.- Opens circuit to coin chute switches and credit button.- Opens circuit to left and right hole switch and "V" replay.- Opens circuit to ball return switch.- Opens circuit to playboard contacts.- Opens circuit to pop bumper and "WOW" lights.
MOTOR 1D	Inside Sw. Second Sw.	<ul style="list-style-type: none">- "Y" relay lockin.- Hole score control switch.
MOTOR 2B	Inside Sw. Second Sw. Third Sw. Fourth Sw.	<ul style="list-style-type: none">- "F", "G", "S", "V", and "X" relay lockin.- "O" and "Q" relay lockin.- "D" and "E" relay lockin.- Resets "AX" relay.
MOTOR 2C (L-POS)	Inside Sw. Second Sw. Third Sw. Fourth Sw. Fifth Sw.	<ul style="list-style-type: none">- "K" relay lockin.- Subtracts ball count unit control switch.- Adds lightbox advance unit.- Hole score control switch.- Resets sequence bank.
MOTOR 3C (S-POS)	Switch.	<ul style="list-style-type: none">- "U" relay lockin.
MOTOR 4A (S-POS)	Switch	<ul style="list-style-type: none">- Resets score units.
MOTOR 4B	Inside Sw. Second Sw. Third Sw.	<ul style="list-style-type: none">- Subtracts ball count unit control switch, last ball only.- Hole score control switch.- Actuates "K" relay.
MOTOR 4C (S-POS)	Inside Sw. Second Sw. Third Sw. Fourth Sw. Fifth Sw.	<ul style="list-style-type: none">- Hole score control switch.- Actuates "AX" and "JX" relays and adds counter.- Actuates left hole kicker.- Actuates right hole kicker.- Resets bonus unit and actuates ball return.

FOR 10¢ COIN
FOR 5¢ COIN
FOR 25¢ COIN

HIS BLADE TO REST
BACKING BLADE WITH
HT PRESSURE.
MAXIMUM AT END OF

CAUTION

board on this machine

wearing proper

on the board

abrasives. Avoid

rs or Abrasive

weaken the

PLAY

(e) ENCLOS

CONTACT