

GOTTLIEB

COIL USAGE AND EQUIVALENTS

COIL NUMBER	TYPE	TYPICAL USAGE	REPLACEMENTS (SEE NOTES)						
2	M	Relay	R20-2	A-487	A-7688	A-9733			
10	M	Relay	R20-3	A-1084	A-7834	A-9742			
15	M	Relay	R20-4	A-3891	A-489	A-7676	A-9735	A-5662 ⁽²⁾	A-7835 ⁽²⁾
25	M	Relay	R20-5	A-7677	A-9736				
3.3	S	1000 S.U.	A20-6 ⁽²⁾	A-1448 ⁽²⁾	A-3537 ⁽²⁾	A-5143 ⁽²⁾	A-940 ⁽²⁾		
A-1084	M	Relay/Tilt	10	R20-3	A-7834	A-9742			
A-11058	M	Spin Delay Relay	A-9617	A-9741	A-16890				
A-1118	M	Trip Bank	C20-1 ⁽¹⁾						
A-1119	M	Trip Bank	C20-3 ⁽¹⁾						
A-12092	S	Chime	A-1943	A-5195	A-622				
A-1318	S	Bank S.U.	A-15555	A-5196	A-9479 ⁽²⁾				
A-1360	M	Hold Lockin							
A-1448	S	Bell, Knocker	A20-6	A-3537	A-5143	A-940	A-1496 ⁽²⁾	A-2563 ⁽²⁾	A-5194 ⁽²⁾
A-1496	S	Drive	SM20-1 ⁽²⁾	A-1448 ⁽²⁾	A-3537 ⁽²⁾	A-5143 ⁽²⁾			
A-1512	S	220V Bank S.U.							
A-1517	M	Trip Relay							
A-15259	S	Score Drive	Note ⁽⁷⁾						
A-15359	M	Relay							
A-1546	S	Flipper	A-5141	A-1657 ⁽²⁾					
A-15555	S	Target Bank Reset	A-1318	A-5196					
A-1560	M	Tilt Trip							
A-16251	M	Interlock							
A-1640	S	Turret Shooter	A20-4	A-5197 ⁽²⁾					
A-1657	S	Flipper	A-1546 ⁽²⁾	A-5141 ⁽²⁾					
A-16570	S	Outhole, Hole Kick							
A-16890	M	Game Over/Tilt for SS	A-9641	A-9617	A-11058				
A-17564	M	Gate, SS Vari-Target	A-20558	A-7112					
A-17875	S	SS Flipper							
A-17876	S	SS Chime							
A-17891	S	Targ Bank Reset-5, SS Roto							
A-18102	S	Targ Bank Reset-3							
A-18318	S	Targ Bank Reset-4							
A-1856	M	Trip Bank-Start Coil							
A-18642	M	Memory Drop Targets							
A-19208	M	D.C. Relay							
A-19217	M	Drop Target Trip							
A-19300	S	Ball Kicker							
A-1943	S	Deflector	A-5195	A-622	A-12092				
A-19508	M	Targ Bank Trip							
A-20095	S	Super Flipper							
A-20558	M	Ball Gate DC	A-7112	A-17564					
A-2069	S	Runway Kicker	A-6088						
A-21741	S		A-1496 ⁽²⁾						
A-2371	S	Shuffle							
A-24161	S	Flipper DC							
A-2435	S	Pop, Multi-Hole Kick.	A20-8	A-4893	A-939				
A-2563	S	Slingshot	A-5194	A20-6 ⁽²⁾	A-1448 ⁽²⁾	A-3537 ⁽²⁾	A-5143 ⁽²⁾	A-940 ⁽²⁾	
A-3104	S	Reel Drive	A-5193						
A-3498	M	30V Hold	A-7836	A-9738					
A-3537	S	Bell, Knocker	A20-6	A-1448	A-5143	A-940	A-1496 ⁽²⁾	A-2563 ⁽²⁾	A-5194 ⁽²⁾
A-3890	M	Start Relay	R20-6	A-5294 ⁽²⁾					
A-3891	M	Interlock, Tilt, Start	15	R20-4	A-489	A-7676	A-9735	A-5662 ⁽²⁾	A-7835 ⁽²⁾
A-487	M	R Type Relay	2	R20-2	A-7688	A-9733			
A-489	M	Free Ball Gate, Start	15	R20-4	A-3891	A-7676	A-9735	A-5662 ⁽²⁾	A-7835 ⁽²⁾
A-4893	S	Pop, Hole, Early Flip	A-20-8	A-2435	A-939				
A-5141	S	Flipper	A-1546	A-1657 ⁽²⁾					
A-5143	S	Bell, Knocker	A-20-6	A-1448	A-3537	A-940	A-1496 ⁽²⁾	A-2563 ⁽²⁾	A-5194 ⁽²⁾
A-5193	S	Score Drive	A-3104						
A-5194	S	Slingshot, Reset	A-2563	A20-6 ⁽²⁾	A-1448 ⁽²⁾	A-3537 ⁽²⁾	A-5143 ⁽²⁾	A-940 ⁽²⁾	
A-5195	S	Ball Stop	A-12092	A-1943	A-622				
A-5196	S	Bank Reset	A-1318	A-15555	A-9479 ⁽²⁾				
A-5197	S	Large Stepup, Roto	A20-4 ⁽²⁾	A-1640 ⁽²⁾					
A-5294	M	Relay	R20-6 ⁽²⁾	A-3890 ⁽²⁾					
A-5457	M	Interlocking Relay	A-6821						
A-5662	M	Dancer Unit	A-7835	15 ⁽²⁾	R20-4 ⁽²⁾	A-3891 ⁽²⁾	A-489 ⁽²⁾	A-7676 ⁽²⁾	A-9735 ⁽²⁾
A-5723	S	Hole Kicker	A-2563 ⁽⁴⁾	A-5194 ⁽⁴⁾					
A-580	S	Kicker	A-24161 ⁽⁵⁾						
A-6088	S	Ball Shooter	A-2069						